








# CABLAGGIO P1-P6 WT8015



REPEATERS + PULSANTIERE BT-USB



**P1 - REPEATER - Trip primario - M8 8 pin femmina**

**P2 - 12V POWER IN - M8 3 pin maschio**

**P3 - SENSORE RUOTA - M8 3 pin femmina**

**P4 - TRIP secondario - M8 4 pin femmina**

**P5 - TABLET WT8 - M8 6 pin maschio**




**P6 - PULSANTIERA - M8 6 pin femmina**



# MAIN CABLE - specs



## REPEATERS + REMOTE control BT-USB



**P1 - REPEATER - Main trip** - M8 8 pin female

**P2 - 12V POWER IN** - M8 3 pin male

**P3 - WHEEL SENSOR** - M8 3 pin female

**P4 - SLAVE trip** - M8 4 pin female

**P5 - TABLET WT8** - M8 6 pin male

**P6 - REMOTE** - M8 6 pin female